

# Warmrails towel warmer and drying rack



Thank you for purchasing this Towel Warmer & Drying Rack, we are sure it will make a valuable addition to your home. As well as warming your towels, it will keep your towels dry and fresh. In fact, you can even use your Warmrail for heating robes and blankets as well as drying laundry items and garments you don't want to put into the tumble dryer!

To get the best results from your Warmrail, towels should be folded over a couple of times to allow the heat to build up in the fiber of the towel. Avoid placing the Warmrail in an area where it is drafty or likely to be knocked over.

To assemble your Warmrail please follow these instructions:

1. Remove the Warmrail from the carton and lay it flat on the floor or a table. Remove the components from the carton and make sure all pieces are present. (Do not try to install the Warmrail if any parts are missing. Contact customer service for replacement parts).
2. Locate the two legs.
3. Insert the top of one leg into the mounting lug on the bottom rail. Press in the locking pin so that the leg slides all the way in to the mounting lug. When the leg is properly installed the locking pin should pop out into the hole in the mounting lug. Repeat the procedure for the second leg. Do not use the Warmrail if you are unable to lock the legs in place securely.
4. Place the Warmrail on level ground and make sure it is sturdy and doesn't rock. (The legs must be firmly attached before turning your Warmrail on).
5. Plug the cord into a 120V outlet and turn the Warmrail on at the switch.
6. Do not immerse the Warmrail in the water or any other liquid.
7. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

Your Warmrail will start to heat up almost immediately and should reach about 130F on the exposed areas. Temperature will vary depending on the temperature of the surroundings. The temperature will be higher in areas where the Warmrail is covered by towels.



**WARNING: Your Towel Warmer & Drying Rack is not a toy. It will heat up and may appear hot to the touch. It is safe to leave your Warmrail running continuously 24 hours a day, but it should be used responsibly at all times.**

**Children should not be allowed to play with your Warmrail!**

This product has a limited warranty for one full year from the date of purchase. Please keep your receipt for your records. If your Warmrail is defective or you have questions, please call toll free (877) 927-8724 before returning it to the store.